

PIONEERPOS Touchscreen Product Cleaning Guide

Applicable models:

- StealthTouch series
- Stealth S-LINE series
- CarisTouch series
- Touch monitor series
- DASH Tablet Series

Cleaning and disinfection directions:

Please turn off the touch monitor or touch terminal before cleaning the screen.

Both touchscreen and plastic bezel of PioneerPOS touchscreen product can be cleaned using any standard glass cleaner. Avoid using any cleaning product that contains ammonia. For disinfection and sanitation, user may use isopropyl alcohol wipes or isopropyl alcohol solution on a soft cloth.

Avoid spraying glass cleaner or isopropyl liquid directly onto the touchscreen or monitor. Always spray cleaning solution onto a soft cloth or towel before cleaning the surface of touchscreen or bezel.

StealthTouch/Stealth S-LINE/Touch monitor





